



Replacement U.V. Tubes & Starters

RS Stock nos. 556-250, 559-990 and 215-9249

Instructions for servicing RS U.V. exposure units.

For exposure units (RS stock no. 555-279) use service set (RS stock no. 556-250).

For exposure units (RS stock no. 559-934) use service set (RS stock no. 559-990).

For exposure unit (RS stock no.196-5251) use service set (RS stock no. 215-9249).

Replacing tubes and starters

Servicing the U.V. exposure units should not be attempted by inexperienced persons. If in doubt, refer to **RS** Service Point. ENSURE THAT THE UNIT IS COMPLETELY DISCONNECTED FROM THE SUPPLY.

Open the lid. Unscrew the left hand end panel and carefully lift out the panel, taking care not to damage the edge of the glass. Slide out the glass panel to the left. Avoid contaminating the under surface of the glass with finger marks etc. The tubes and starters are now accessible. Replace the defective or suspect tube(s) or starter(s) with new items from the **RS** service set. Starters twist and unplug from their sockets, tubes must be rotated through 90° before lifting out. When testing, do not view the illuminated tubes from a close distance for an extended period.

Cleaning

Carefully clean both sides of the glass before re-assembly. A damp soft cloth should be sufficient. Under no circumstances use solvents or abrasives which could damage the surface of the glass, or damage or remove the masking.

Re-assembly

Re-assembly is the reverse of dismantling, but note that the left hand side panel must be the correct way up in order to accommodate and protect the edge of the glass in the slot provided. Do not over-tighten the screws.