

## 13 mm, Coarse 60 Grit

The band is made out of aluminum oxide. Coarse 60 Grit.

**Tips & Tricks:**

Ideal for rough shaping and smoothing wood and fiberglass; removing rust from metal surfaces; shaping rubber surfaces. Sander bands are easily replaceable on drums. We advice to use a slow speed with this accessory. Start your work with the coarse bands or disks and finish with the finer grits. Your sanding will be most effective when you use a very light touch.



**Part Nr:**  
2615040832

**EAN Code:**  
8710364007633

**Tools for this accessory:**

- [Multi Tools & Kits](#)
- [Cordless Multi Tools & Kits](#)
- [Multi Purpose Flex-Shaft Tools & Kits](#)

**Special attachments for this accessory:**

[407](#)

**Speed settings:**

	Multi	Cordless
soft wood	3	-
hard wood	3	-
plastic	1-2	1-2
steel	1	1
aluminum,brass,etc.	2	2

**Projects for this accessory:**

- [Repair a Dent](#)
- [Sand Window Trim](#)
- [Repair Trailer Rust](#)
- [Loosen a Sticky Door](#)
- [Make Adjustable Shelves](#)
- [Install Cabinet Lighting](#)