

13 mm, Coarse 60 Grit

The band is made out of aluminum oxide. Coarse 60 Grit.

Tips & Tricks:

Ideal for rough shaping and smoothing wood and fiberglass; removing rust from metal surfaces; shaping rubber surfaces. Sander bands are easily replaceable on drums. We advice to use a slow speed with this accessory. Start your work with the coarse bands or disks and finish with the finer grits. Your sanding will be most effective when you use a very light touch.

**Part Nr:**

2615040832

EAN Code:

8710364007633

Tools for this accessory:[Multi Tools & Kits](#)[Cordless Multi Tools & Kits](#)[Multi Purpose Flex-Shaft Tools & Kits](#)**Special attachments for this accessory:**[407](#)**Speed settings:**

	Multi	Cordless
soft wood	3	-
hard wood	3	-
plastic	1-2	1-2
steel	1	1
aluminum,brass,etc.	2	2

Projects for this accessory:[Repair a Dent](#)[Sand Window Trim](#)[Repair Trailer Rust](#)[Loosen a Sticky Door](#)[Make Adjustable Shelves](#)[Install Cabinet Lighting](#)