

The printer side connector is a moulded connection, with the user connector being a Molex 51021 series female connector. Fuller details on this can be found below:

EPM device connector J4	User side matching connector
Molex, 53047 Series 5 contacts (male)	Molex 51021 Series (female) Contacts: 50079/50058.

Pin number	Signal name
1	Gnd
2	Transmit data (Txd, printer output)
3	Receive data (Rxd, printer input)
4	CTS/DSR (printer input)
5	RTS/DTR (printer output)

The host device end of this cable can be a D-sub plug or any other connector capable of carrying the necessary RS232 signals.